



**CAUTIONS & SAFEGUARDS IMPORTANT INSTRUCTIONS AND SAFEGUARDS!
PLEASE READ INSTRUCTIONS CAREFULLY PRIOR TO USAGE. USE THE
PRODUCT ONLY IF YOU UNDERSTAND THE CAUTIONS PRESENTED.**



CAUTION - TOY CONTAINS ELECTRONICS!

Not recommended for children under 3 years of age. As with all products containing electronics, precautions should be observed during handling and use. Adult assembly required. Please review all important safeguards and operating procedures before usage.

It is parents' responsibility to check main parts of the toy before using. Regularly examine for potential hazard, such as the battery. In the event of any damage the toy must not be used until that damage had been properly removed.

NON-MEDICAL PURPOSE

This product and the accompanying software are not medical devices. Do not use them for diagnostic purposes, nor as a substitute for the medical advice or supervision of your personal physician. If the results obtained by Teddy the Guardian's sensors show a deviation from the normal vital values, we recommend repeating the measurement process with conventional medical devices.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

POWER SOURCE



Power source is a CR2450 coin battery. It has to stay undamaged, otherwise it can be flammable or explosive. Do not load or transport battery if you think you damaged it in any way. If you experience difficulties with the battery, do not try to repair electronics yourself. Rather disconnect the sensor enclosure and contact Customer support via support@idguardian.co

INTERFERENCES

Connection between the product and the mobile App is wireless and can be disrupted by electromagnetic interferences of any nature.

Do not place this product in close proximity to other devices that can cause electromagnetic interferences of any nature, do not use it in the presence of a **FLAMMABLE ANAESTHETIC MIXTURE WITH AIR, OXYGEN OR NITROUS OXIDE**. Electronic equipment in the product requires special precautions regarding electromagnetic environments (EMC). In event of loss connection between the product and the mobile App it is necessary to slightly move the Teddy's paw to turn it on and restore the wireless connection.

HEAT AND MOISTURE

Avoid exposing the product to extreme temperatures, direct sunlight, moisture, sand, dust, or mechanical shock. Never spill liquid of any kind into the product.

SKIN SENSITIVITY

The materials of which the product is made have been evaluated for skin contact. Because everyone's skin is different your child may experience allergic reactions. If this occurs, discontinue usage and consult your physician.

MAINTENANCE AND CARE



The plush exterior is washable. All electrical parts must be removed prior to washing. Do not wash it if the internal parts remain inside the toy. This product is washable strictly under 30 °C maximum. The mechanical drying is forbidden.

DAMAGE REQUIRING REPLACEMENT OR REPARATION

If the electronics or battery become damaged do not try to repair them yourself. It may result the risk of fire, electric shock, or injury. Do not attempt to service the unit yourself as opening or removing covers may expose you to various hazards. All servicing should be referred to qualified personnel. If assistance is needed please contact us via support@idguardian.co